



- 1- BARREL
- 2- RECEIVER
- 3- STOCK
- 4- FOREARM
- 5- BUTT PLATE / RECOIL PAD
- 6- BUTT PLATE SCREW
- 7- STOCK BOLT WASHER
- 8- STOCK BOLT
- 9- SWIVEL PIN
- 10- SWIVEL
- 11- FRONT SWIVEL STUD
- 12- TRIGGER GUARD
- 14- SAFETY SELECTOR
- 15- SAFETY PIN
- 16- SAFETY SPRING PIN
- 17- HAMMER SPRING PLUNGER
- 18- HAMMER SPRING
- 20- TRIGGER PIN
- 21- SEAR-SAFETY SPRING
- 22- SEAR-SAFETY SPRING
- 23- SEAR (RIGHT)
- 24- SEAR (LEFT)
- 25- HAMMER (LEFT)
- 26- HAMMER (RIGHT)
- 27- LOWER RECEIVER
- 28- SAFETY EXTRACTOR
- 29- SINGLE TRIGGER
- 31- SEAR PIN
- 32- STOCK SWIVEL STUD
- 33- LEFT EXTRACTOR
- 34- RIGHT EXTRACTOR

- 37- EXTRACTOR
- 40- FOREARM COCKING ARM
- 41- FIRING PIN SPRING
- 43- TOP LEVER
- 44- LEFT EJECTOR EXTRACTOR
- 45- RIGHT EJECTOR EXTRACTOR
- 46- LEFT AND RIGHT LEVER EXTRACTOR
- 47- EJECTOR EXTRACTOR SPRINGS
- 48- EJECTOR EXTRACTOR PINS
- 49- EJECTOR LEVER SPRING
- 50- EJECTOR EXTRACTOR LEVER PIN
- 51- LOCKING BLOCK
- 52- FOREARM IRON
- 53- TAKE DOWN LATCH BRACKET
- 54- TAKE DOWN LATCH
- 55- TAKE DOWN LATCH SPRING
- 56- FOREARM SCREW
- 57- ESCUTCHEON SCREW
- 58- TAKE DOWN LATCH PIN
- 59- ESCUTCHEON MORTISE LOCH
- 60- FRONT BEAD
- 61- TOP LEVER PLUNGER
- 62- TOP LEVER SPRING
- 63- TOP LEVER PIN
- 64- COCKING ARM
- 65- HAMMER PIN
- 66- LOWER RECEIVER PIN
- 67- FIRING PIN RETAINIG PIN
- 68- FIRING PIN (TOP)
- 69- FIRING PIN (BOTTOM)